

Time Set KX-TDA, TDE, NCP, TAW848

Systems automatically adjust for Daylight Savings Time

<i>KEYSTROKES</i> <i>(Press these keys on the phone designated for programming)</i>	
Press PROGRAM, STAR, STAR, 1234	(Default password is 1234. yours may have been changed)
Press SP-PHONE	Display shows Date & Time Set
Press ENTER (or Auto Dial/Store)	Display will show year, month and date
Press the button below NEXT on the display	Display will show flashing hour.
Enter the 2-digit hour	Such as 03 or 11
Enter the 2-digit minute	Such as 06 or 44
If needed, set AM or PM	Not necessary if correct or change by pressing SEL+
Press ENTER on the Navigator Wheel or the button labeled Auto Dial/Store.	New time is now stored.
Lift handset and hang up to leave programming mode or press exit	