

Program Station Names

KX-TDA 50/100/200 KX-TDE100/200

In order to change names, it is necessary to know the STATION number of the station.

Names can only be programmed from phones allowed this feature.

Example below is for the phone located at Station 121. Name to be entered is Bob

KEYSTROKES	DISPLAY READS
Press PROGRAM, STAR, STAR, 1234 004	004 Ext Name
Press ENTER (or key under ENTER on display)	Ext Name Ext No?
Enter the Extension Number	121
Dial 2 (for the B in Bob)	Display will read 2
Press the 2 until B shows on the display	B
Press 6 (for the o in Bob)	Display will read B2
Press the 6 until o shows on the display	Bo
Dial 2 (for the b in Bob)	Display will read Bo2
Press the 2 until b shows on the display	Bob
Press ENTER or STORE to save	

If you press 6 to enter M and then want to enter O, press the button under the right facing arrow to move the cursor to the right, the press 6 until the o shows on the display.