

Auto Dial/System Speed Dial

How do I use system speed dial?

AUTO DIAL/STORE button: Dual purpose button for speed dialing and storing program changes.

KX-TDA, TDE, NCP & TAW848 analog system: [CLICK](#)

KX-TD 308, KX-TD 816, KX-TD 1232, KX-TD 500 and KX-TA 1232 Analog System

INTERCOM, AUTO DIAL/STORE, Enter 3-digit number 000-999

INTERCOM, AUTO DIAL/STORE, Enter 3-digit number 000-499

Older software versions are 00 to 99.

KX-TA 308, KX-TA 624, KX-TA 824, KX-TA 824

KX-T308 KX-T 616 KX-T 1232

INTERCOM, AUTO DIAL/STORE, Enter 2-digit number 00-99

Single-Line/Cordless Phones

Pick up the handset or turn on dial tone

Press the STAR key (STAR STAR on TDA and TAW Systems)

Dial the 2-digit or 3-digit speed dial number depending on your system model.

Number will be automatically dialed.